

~~~~~

# LaZee News

**Issue #2**  
**Spring 2006**

~~~~~

In this issue

- Introduction & Thanks
- Product News
- SALE - HUGE Savings on Last Years models
- Mounting Tip
- Operational Tips

Hello LaZee News Subscribers

Welcome to LaZee News, a quarterly newsletter from LaZee Tek, an AT manufacturer of computer access products. We are pleased to share our newsletter with you, and intend this forum to be an informative media to relay information that will benefit both you and ultimately your consumers. Please share this newsletter with anyone you feel might benefit from its content.

Introduction & Thanks

~~~~~

While we thank all of you for your support and your feedback, we take this opportunity to give a special thanks to:

Anne Banton - ATEN who was quick to recognize the need for a DIP switch on our mice, providing the user with control over their clicking options.

Nancy Mashberg - FAAST who influenced adding an external switch input on our LaZee Mouse CURSOR, allowing users to reset their "Home" position.

As with any good publication, we need your input to ensure LaZee News provides you the type of product information you want to see. Please drop us an email at [feedback@lazeetek.com](mailto:feedback@lazeetek.com) and let us know what you would like to see in future issues.

## **Product News**

~~~~~

NEW PRODUCTS!

The **LaZee Mouse Switch** and the **LaZee Mouse Cursor** models are officially released! These products were postponed in order to incorporate some valuable suggestions received at Closing the Gap.

The LaZee Mouse **Switch** provides the same proportional cursor control as the original LaZee Mouse Pro unit, and performs real time clicks via switch input(s). MSRP \$995

The LaZee Mouse **Cursor** provides the same proportional cursor control as the Pro, but without any clicking functionality. The input jack allows an external switch to set/reset the "Home" position. MSRP \$795

Upgraded Product!

The LaZee Mouse PRO has a new feature. A DIP switch has been added to allow easy selection of which clicking option is desired. Anyone who has previously purchased a LaZee Mouse Pro that is under warranty, is eligible to exchange their unit for a new one with the DIP switch. Please contact us if you would like to do so.

The entire LaZee Mouse series share the same basic Universal Design characteristics and 2 year warranty.

- Quick Set-up, Easy to Operate
- No Software to Install
- Works on Desktops, Laptops, & Aug Com devices
- Works with all existing mice, touch pads, trackballs, etc.
- Compatible with all Software Products
- Same Lightweight, Portable, Self-Contained Case
- Connects to host computer via single USB cable
- FREE DEMO UNITS are available for evaluations

The "Headmouse" isn't just for the head anymore!

[LaZee Mouse Family](#)

SALE - HUGE Savings on Last Years models



~~~~~  
~~~~~

We have a limited supply of 2005 Model year closeouts. Take advantage of this opportunity to build your equipment library at a substantial savings.

New 2005 models (no DIP switch) at a 40% savings.

Used 2005 models including the full 2-year warranty at a 60 % savings.

Order yours today before they're gone. Limited

supplies available.

Mounting Tip

~~~~~

This issue's suggestion is from the UK, and uses the LaZee Mouse **Switch** in conjunction with AbleNet's **Specs-Switch** TM.

The switch is placed into the palm of the user's hand and fastened into place by wrapping the Velcro TM strap over the back of the hand. The hand can then be closed and relaxed. The LaZee Mouse Switch then is attached to the strap on the top of the hand.

The hand is placed where it is to be used, possibly against the body, and can be steadied with the other hand. The cursor is moved by tilting the hand. When clicking is desired, the switch is activated by closing finger(s) on the switch.

We admit this implementation for using our "Hands- Free" mouse does indeed use one or both "hands". "Hands-Free" refers to being able to operate the mice without REQUIRING the use of hands, not that hands CAN'T be used.

We encourage submissions from everyone. If your suggestion or experience is selected for publication, you will receive a free LaZee Mouse Pro T-Shirt and a \$50 LaZee Tek gift certificate. Send your suggestions to [feedback@lazeetek.com](mailto:feedback@lazeetek.com) today!

## Operational Tips

~~~~~

This continuing section will provide users helpful information on using our products and/or other computer equipment.

A common **misconception** is that the LaZee Mouse must be positioned in front of the computer, monitor, or positioned just right so an invisible laser, infra-red, or other such link can operate.

This is NOT True.

The LaZee Mouse is connected to the host computer with the USB cable. This cable passes ALL communications that need to occur. This frees the LaZee Mouse to be located anywhere the user desires to operate it: under the table, behind things, close to noise sources, etc..

USB Extension cables may be used if longer cable lengths are needed. As with any USB compliant device, up to 30 feet is acceptable (per USB 2.0 specification)

[More Tips](#)

Contact Information

~~~~~

email: [info@lazeetek.com](mailto:info@lazeetek.com)

phone: 260 351-3274

web: <http://www.lazeetek.com>

~~~~~